


FIG.1










FIG.5






FIG.6







#11 #24 #10 #15 **\$** -320 INFORMATION VACANCY TIMING #14 \$ \$ 802 NW-SIDE FRAME BUFFER BTS-SIDE FRAME BUFFER #13 **1 1**# INFORMATION VACANCY TIMING #20 #12 9# 9# HO TIMING 800 #19 #11 帮 #2 #18 #10 # # 6# 8 8# 8 #17 #3 #3 801 #16 # #2 #15 **2**# #1

351 (FRAME INFORMATION 350 CONTROL TABLE 352 353 354 3				55 356
FRAME BUFFER NUMBER	DOWNLINK FRAME		UPLINK FRAME		SWITCHING
	SPECIFIC NUMBER	EXISTENCE OF INFORMATION	SPECIFIC NUMBER	EXISTENCE OF INFORMATION	FRAME INFORMATION
#1	#15	YES	#7	YES	0
#2	#16	YES	#8	YES	0
#3	#17	NO	#9	YES	. 0
#4	#18	NO	#10	NO	3
#5	#19	NO	#11	NO	2
#6	#20	NO	#12	NO	1
#7	#21	YES	#13	NO	0
	:	:	•	:	:
#n	#m	NO	#k	NO	1